RS-232 Data Acquisition Module Model 232SDA12

Document No. 232SDA12-0308

This product designed and manufactured in Ottawa, Illinois USA of domestic and imported parts by



707 Dayton Road -- P.O. Box 1040 -- Ottawa, IL 61350 USA Phone (815) 433-5100 -- General Fax (815) 433-5105

Phone (815) 433-5100 -- General Fax (815) 433-5105

Website: www.bb-elec.com

Sales e-mail: orders@bb-elec.com -- Fax (815) 433-5109
Technical Support e-mail: support@bb.elec.com -- Fax (815) 433-5104

European Headquarters

B&B Electronics

Westlink Commercial Park -- Oranmore, Co. Galway, Ireland

Phone +353 91-792444 -- Fax +353 91-792445

Website: www.bb-europe.com
Sales e-mail: sales@bb-europe.com

Technical Support e-mail: support@bb-europe.com

© 1995 B&B Electronics -- Revised January 2008

Manual Documentation Number: 232SDA12-0308 Cover Page

B&B Electronics Mfg Co Inc - 707 Dayton Rd - PO Box 1040 - Ottawa IL 61350 - Ph 815-433-5100 - Fax 815-433-5104
B&B Electronics Ltd - Westlink Commercial Park - Oranmore, Galway, Ireland - Ph +353 91-792444 - Fax +353 91-792445

Table of Contents

Chapter 1- Introduction	1
232SDA12 Features	1
Packing List	2
Software Installation	
Uninstall	
Getting Started	
232SDA12 Specifications	
Chapter 2 - Connections	6
A/D Connections	6
A/D Inputs #Ø-1Ø	6
A/D Ref Input +	
A/D Ref Input	7
Analog Ground	7
Typical Connections	7
Digital I/O Connections	8
Digital Inputs #Ø-2	
Digital Outputs #Ø-2	
Digital Ground Typical Connections	
Serial Port Connections	
Power Supply Connections	
• • •	
Chapter 3 - Commands	12
Syntax	13
Reading A/D Channels Command	
Reading Digital I/O Command	
Set Digital Output Command	
Chapter 4 - A/D	17
Sampling Rate	
A/D Input Range	
Reference Inputs	
Data Range	
Converting Data	
Chapter 5 - Software	20
Read A/D Command	
Read Digital I/O Command	
Set Digital Output States	

232SDA12-0308 Manual

Table of Contents

B&B Electronics Mfg Co Inc - 707 Dayton Rd - PO Box 1040 - Ottawa IL 61350 - Ph 815-433-5100 - Fax 815-433-5104 B&B Electronics Ltd - Westlink Commercial Park - Oranmore, Galway, Ireland - Ph +353 91-792444 - Fax +353 91-792445

Appendix A: Adding Data Field Confirmation 1
Appendix B: Analog Input Impedance1
Appendix C: Decimal to HEX to ASCII Table 1
Figures
FIGURE 1.1 - 232SDA12 UNIT
FIGURE 1.2 - GENERAL BLOCK DIAGRAM
FIGURE 1.3 - A/D WITH VARIABLE RESISTOR
FIGURE 2.1 - TYPICAL Ø-5V A/D CONNECTION7
FIGURE 2.2 - TYPICAL DIGITAL I/O CONNECTIONS9
FIGURE 4.1 - A/D CONVERTER DATA RANGE
FIGURE B-1 - EQUIVALENT INPUT CIRCUIT INCLUDING THE DRIVING
SOURCEB-3
Tables
TABLE 2.1 - 232SDA12 I/O PORT PINOUT
TABLE 2.2 - RS-232 CONNECTOR PINOUT
TABLE 2.3 - 232SDA12 TO DTE CONNECTIONS
TABLE 2.4 - 232SDA12 TO DCE CONNECTIONS
TABLE 3.1 - 232SDA12 COMMANDS
TABLE 3.2 - EQUIVALENT VALUES
TABLE 3.3 - READ A/D RESPONSE
TABLE 3.4 - READ DIGITAL I/O RESPONSE FOR OUTPUTS
TABLE 3.5 - READ DIGITAL I/O RESPONSE FOR INPUTS 16
TABLE 3.6 - SET DIGITAL OUTPUT DATA BYTE VALUES16
TABLE 5.1 - DIGITAL I/O MASK VALUES
TABLE A-1 - EXTENDED COMMANDS
TABLE C-1 - DECIMAL TO HEX TO ASCII TABLE

Chapter 1- Introduction

232SDA12 Features

The 232SDA12 is a general purpose control module that is connected to your computer's RS-232 serial port. The 232SDA12 offers 11 channels of 12-bit A/D (analog to digital), 3 digital inputs and 3 digital outputs. With these features, the module can be used to sense a variety of external conditions and to control a variety of devices.

The 11 A/D channels allow you to measure voltages from Ø to 5 Volts. The 3 digital inputs and 3 digital outputs are CMOS/TTL compatible. The A/D and digital I/O lines are available through a DB-25S (female) connector.

The 232SDA12 connects to your computer's RS-232 serial port through a DB-25S connector. The unit automatically detects baud rates from 12ØØ to 96ØØ. A data format of 8 data bits, 1 stop bit and no parity is used.

The unit may be powered by setting RTS and/or DTR high on the serial port. If the 232SDA12 cannot be powered using the handshake lines, it may be powered using a 2.5mm jack. The 232SDA12 requires 12V DC @ 5mA (not including the power consumption of external devices).

NOTE: When using an external supply, connect the supply only to specifically labeled power inputs (power jack, terminal block, etc.). Connecting an external power supply to the handshake lines may damage the unit. Contact technical support for more information on connecting an external power supply to the handshake lines.



Figure 1.1 - 232SDA12 Unit




Figure 1.2 - General Block Diagram

Packing List

Examine the shipping carton and contents for physical damage. The following items should be in the shipping carton:

- 232SDA12 unit
- One 232SDA12 3.5" disk
- This instruction manual

If any of these items are damaged or missing contact B&B Electronics immediately.

Software Installation

The 232SDA12 comes with several useful programs such as a data logging utility, a demonstration program, etc. The installation for the SDA Logger is different depending on the platform you install it to. Please use the one appropriate to your system.

Windows

- Insert the SDA Logger installation disk in your CD ROM drive.
- 2. Click Start | Run.
- 3. Click the Browse button and choose the drive containing the SDA Logger installation disk.
- 4. Double click the Setup.exe icon when it appears.

232SDA12-0308 Manual

2

B&B Electronics Mfg Co Inc - 707 Dayton Rd - PO Box 1040 - Ottawa IL 61350 - Ph 815-433-5100 - Fax 815-433-5104
B&B Electronics Ltd - Westlink Commercial Park - Oranmore, Galway, Ireland - Ph +353 91-792444 - Fax +353 91-792445

- 5. Click the OK button to run the Setup.exe program.
- 6. Follow the installation instructions as prompted.

Uninstall

Uninstall for the SDA Logger version is different for each Windows operating system. Below are the methods for uninstalling the SDA Logger.

Windows

- 1. Open Start | Settings | Control Panel.
- 2. Open ADD/REMOVE PROGRAMS.
- 3. Click SDA LOGGER.
- 4. Click the Add/Remove button.
- 5. Follow the Uninstall Wizard.

Getting Started

This section will provide a quick example using the 232SDA12 and the demonstration program. If you experience any problems, refer to Chapter 2 for more precise information on connections. The demo program continually reads the A/D inputs and the digital I/O. The states of the digital outputs can be toggled using F2, F3, and F4. The serial port is configured for 96ØØ baud, 8 data bits, no parity, and 1 stop bit. The program supports standard addresses and IRQ's for COM1 and COM2.

- Connect a Ø to 5V DC analog device to A/D input #Ø, or you can connect a variable resistor as shown in Figure 1.3. The variable resistor must be greater than 1k Ohms to limit the output current to 5mA.
- Connect A/D Ref Input+ to +5V DC.
- Connect A/D Ref Input- to analog ground (See Figure 1.3).
- Connect the 232SDA12 to a standard IBM serial port using a straight through cable or a standard DB-9 to DB-25 adapter cable.

Once your connections have been made, run the demo program. The demo program automatically raises RTS and DTR to power the unit. Any change in A/D or digital lines on the 232SDA12 will automatically be displayed on the screen.




Figure 1.3 - A/D with Variable Resistor

232SDA12 Specifications

Analog to Digital Converter

Resolution: 12 bit Channels: 11

Reference Range: 5.ØV DC max. (1.211 mV per bit)

2.5V DC min. (Ø.61Ø mV per bit)

A/D Ref. Input - ØV DC to 2.5V DC
A/D Ref. Input + 2.5V DC to 5.ØV DC
Input Voltage Range: -Ø.3V DC to 5.3V DC
Total Unadjusted Error: +/- 1 LSB max.

A/D input channels must be driven from a source impedance less

than $1k\Omega$.

5 Volt Reference

Output Voltage: 4.975 to 5.Ø25V DC (5.ØV DC typ.)

Accuracy: +/- Ø.5 %
Output Current: 5mA max.

Digital Inputs

Channels: 3

Voltage Range: -3ØV DC to 3ØV DC
Low Voltage: -3ØV DC to 1.ØV DC
High Voltage: 2.ØV DC to 3ØV DC
Leakage Current: 1 microamp max.

Digital Outputs

Channels: 3

Low Voltage: Ø.6V DC @ 8.7mA High Voltage: 4.3V DC @ -5.4mA

Power Supply

Input Voltage: 7V DC to 18V DC @ 5mA

(Doesn't include the power

consumption of external devices.)

NOTE: If RTS and/or DTR are high, the RS-232 port powers the

unit.

Communications

Standard: RS-232 (unit is DCE)

Baud Rate: 12ØØ to 96ØØ (automatic detection) Format: 8 data bits, 1 stop bit, no parity

Connector: DB-25S (female)

232SDA12-0308 Manual

Chapter 2 - Connections

This chapter will cover the connections required for the 232SDA12. There are four sets of connections:

- A/D converter
- Digital I/O
- Serial port
- Power supply

Do not make any connections to the 232SDA12 until you have read this chapter.

Caution: When making electrical connections it is important to power down the devices being connected. If this is not possible, precautions must be taken to ensure electrical specifications are not exceeded.

Note: If you do not intend to use a section (A/D or I/O), it is still important to read each one.

A/D Connections

The A/D connections are made on the I/O port, which is a DB-25S (female) connector. Table 2.1 shows the pinout of the I/O port. The next sections explain the functions and connections for the various analog signals.

A/D Inputs #Ø-1Ø

These are the analog input channels. The analog data that is read from the 232SDA12 is related to the voltage on these pins. Connect your devices to the analog input channels. A/D input channels must be driven from a source impedance less than $1k\Omega$. Connect unused A/D inputs to analog ground.

A/D Ref Input +

The voltage connected to this pin determines the upper end of the input voltage range. For proper operation, this pin must be connected to a DC voltage between +2.5 and +5.0 Volts. The 232SDA12 provides a 5.0V +/-0.5% reference on pin 17. The 5V reference can be used if you require a 0 to 5V DC input range. If your application requires a better reference voltage or a different input range, you must supply the appropriate reference to the A/D Ref Input+ pin. This voltage must be at least 2.5V greater than A/D Ref Input-. Bypassing the A/D Ref Input+ pin with

 $\varnothing.\varnothing1\mu F$ ceramic and $1\varnothing\mu F$ tantalum capacitors to analog ground will decrease noise levels.

A/D Ref Input -

The voltage connected to this pin determines the low end of the input voltage range. For proper operation, this pin must be connected to a DC voltage between \varnothing and +2.5 Volts. Typically, this is connected to your device's ground and analog ground $(\varnothing V)$.

Analog Ground

This pin should be connected to your analog device's ground. If ground (ØV) is the low end of your input voltage range, A/D Ref Input- should be connected to this pin. To minimize noise **do not connect** analog ground and digital ground together. Connect unused A/D inputs to analog ground.

Typical Connections

Figure 2.1 shows the typical connections of the 232SDA12 for a \varnothing to 5V DC input range.




Figure 2.1 - Typical Ø-5V A/D Connection

Digital I/O Connections

The digital I/O connections are made on the I/O port, which is a DB-25S (female) connector. Table 2.1 shows the pinout of the I/O port. The next sections explain the functions and connections for the various digital signals.

Table 2.1 - 232SDA12 I/O Port Pinout

DB-25S Pin #	Function	DB-25S Pin #	Function
1	GND	14	Digital Output #Ø
2	+12V DC Output*	15	Digital Output #1
3	Digital Input #Ø	16	Digital Output #2
4	Digital Input #1	17	+5V DC Output
5	Digital Input #2	18	A/D Ref. Input +
6	Digital GND	19	A/D Ref. Input -
7	Analog GND	2Ø	No connection
8	A/D Input #Ø	21	A/D Input #6
9	A/D Input #1	22	A/D Input #7
1Ø	A/D Input #2	23	A/D Input #8
11	A/D Input #3	24	A/D Input #9
12	A/D Input #4	25	A/D Input #1Ø
13	A/D Input #5		

^{*}Actual output is equal to power supply input minus Ø.7V

Digital Inputs #Ø-2

The digital input lines are CMOS/TTL compatible and can handle voltages from -3ØV DC to +3ØV DC. If a digital input is from -3ØV DC to 1.ØV DC, the state will be read as a "Ø" (LOW). If a digital input is from 2.ØV DC to 3ØV DC, the state will be read as a "1" (HIGH). Connect unused digital inputs to digital ground.

Digital Outputs #Ø-2

The digital output lines are CMOS/TTL compatible. A digital output that is set to a "Ø" (LOW) will output a voltage from Ø to Ø.6V DC. A digital output that is set to a "1" (HIGH) will output a voltage from 4.3V DC to 5.ØV DC. Refer to Chapter 1, Specifications, for more information. Unused digital output lines may be left open.

Digital Ground

Connect the digital ground pin to your digital device's ground. To minimize noise **do not connect** analog ground and digital ground together. Connect unused digital inputs to digital ground.

Typical Connections

Figure 2.2 shows the typical connections of the 232SDA12 for the digital I/O lines.




Figure 2.2 - Typical Digital I/O Connections

Serial Port Connections

To communicate to the 232SDA12 module, it must be connected to an RS-232 serial port. The unit automatically detects baud rates from 12ØØ to 96ØØ. A data format of 8 data bits, 1 stop bit and no parity is used. The 232SDA12 is configured as a DCE device (See Table 2.2). If your communications equipment is configured as a DTE device, such as a standard IBM PC serial port, connect the 232SDA12 using a "straight through" DB-25 cable or a standard DB-9 to DB-25 cable adapter as shown in Table 2.3. If your communications equipment is configured as a DCE device, such as a modem, connect the 232SDA12 using a "null modem" cable (See Table 2.4).

Table 2.2 - RS-232 Connector Pinout

DB-25S		232SDA12	
Pin #	Signal	Function	Notes
2	Transmit Data (TD)	Input	Connection is required.
3	Receive Data (RD)	Output	Connection is required.
4	Request to Send (RTS)	Input	May be used to power unit if kept high.
5	Clear to Send (CTS)		Internally connected to RTS (pin 4).
6	Data Set Ready (DSR)		Internally connected to DTR (pin 2Ø).
7	Signal Ground (SG)		Connection is required.
8	Data Carrier Detect (DCD)		Internally connected to to DTR (pin $2\emptyset$).
2Ø	Data Terminal Ready (DTR)	Input	May be used to power unit if kept high.

Table 2.3 - 232SDA12 To DTE Connections

232SDA12 Pin #	Signal	DTE DB-25 Connection	DTE DB-9 Connection
2	Transmit Data (TD)	2	3
3	Receive Data (RD)	3	2
4	Request to Send (RTS)	4	7
5	Clear to Send (CTS)	5	8
6	Data Set Ready (DSR)	6	6
7	Signal Ground (SG)	7	5
8	Data Carrier Detect (DCD)	8	1
2Ø	Data Terminal Ready (DTR)	2Ø	4

Table 2.4 - 232SDA12 To DCE Connections

232SDA12 Pin #	Signal	DCE DB-25 Connection	DCE DB-9 Connection
2	Transmit Data (TD)	3	2
3	Receive Data (RD)	2	3
4	Request to Send (RTS)	5	8
5	Clear to Send (CTS)	4	7
6	Data Set Ready (DSR)	2Ø	4
7	Signal Ground (SG)	7	5
8	Data Carrier Detect (DCD)	N/C	N/C
2Ø	Data Terminal Ready (DTR)	6	6

Power Supply Connections

The 232SDA12 requires 7 to 18 V DC at 5mA. Power can be supplied either through the serial port's handshake lines (RTS, DTR) or through the 2.5mm power jack. Most serial ports can provide enough power to supply the 232SDA12's 5mA requirement. If you use this method to power the unit, your software must set RTS and DTR high. Remember that the 5mA requirement doesn't include the power consumption of any external devices. Therefore, any current sourced with the digital outputs must be added to this value.

Chapter 3 - Commands

There are only three commands required to control the 232SDA12:

- Read A/D command
- Read digital I/O command
- Set output states command

The command string consists of four bytes. The read A/D and digital I/O commands require an additional data byte. For information on adding checks to the data fields refer to Appendix A. See Table 3.1.

Table 3.1 - 232SDA12 Commands

Function	Command	Response
Read A/D Channels	!ØRA{#}	{ch#msb}{ch#lsb}{ch(#-1)msb} {chØmsb}{chØlsb}
Read Digital I/O	!ØRD	{I/O states}
Set Output States	!ØSO{#}	no response

NOTE: Each {...} represents one byte.

Before going into the specifics of each command, it is important to understand that a byte has a value from \varnothing to 255 and can be represented in decimal (\varnothing to 255), hexadecimal (\varnothing to FF), or by an ASCII character. The commands in Table 3.1 are shown in ASCII, for example:

<u>ASCII</u>	<u>Hex</u>	<u>Decimal</u>
!ØRD	<21><3Ø><52><44>	(33)(48)(82)(68)


The decimal and hexadecimal equivalents of some ASCII characters are shown in Table 3.2. Notice that the ASCII representation of the character "Ø" does not have a value of Ø. Refer to Appendix C for more ASCII, decimal, and hexadecimal equivalents.

Table 3.2 - Equivalent Values

ASCII	Decimal	Hexadecimal			
!	33	21h			
Ø	48	3Øh			
Α	65	41h			
D	68	44h			
0	79	4Fh			
R	82	52h			
S	83	53h			
NUL	Ø	Øh			
SOH	1	1h			
STX	2	2h			
ETX	3	3h			
EOT	4	4h			
ENQ	5	5h			
ACK	6	6h			
BEL	7	7h			

Syntax

The command string consists of four bytes. The first byte is the start of message byte. The start of message byte is always the "!" character. The second byte is the address byte. This byte allows each unit to have a unique address (useful in RS-485 networks). Since the 232SDA12 uses RS-232 communications, this byte is the ASCII "Ø" (zero) character and can not be changed. The next two bytes are the command characters. These bytes are used to specify which command the module will execute. The read A/D and digital I/O commands require an additional data byte.



Reading A/D Channels Command

The Read A/D channels command returns two bytes for each channel read. The two bytes represent the most significant byte (MSB) and least significant byte (LSB) of the reading. The MSB is received first, followed by the LSB. This command requires a data byte. The data byte is used to specify the number of the highest channel to be read. All channels less than this channel will be read as well. For example, if the data byte has a value of 6, then channels Ø to 6 will be read. The highest channel is read first. Command Syntax

!ØRA{#}

Where "{#}" is a byte that specifies the number of the highest channel to be read. See Table 3.3 Response Syntax

{ch(#)MSB}{ch(#)LSB}{ch(#-1)MSB}...{chØMSB}{chØLSB}The most significant byte of the channel specified is received first. The least significant byte and the lower channels will follow in descending order. "{chxMSB}" and "{chxLSB}" represent the most and least significant bytes of the A/D conversion result.

Table 3.3 - Read A/D Response

140.000 11044 742 1100 001.00				
# of Channels Specified		Response		
		40011	Channels Returned	Bytes
decimal	Hex	ASCII	(order of response)	Returned
Ø	Ø	NUL	Channel Ø	2
1	1	SOH	Channels 1,Ø	4
2	2	STX	Channels 2,1,Ø	6
3	3	ETX	Channels 3,2,,Ø	8
4	4	EOT	Channels 4,3,,Ø	1Ø
5	5	ENQ	Channels 5,4,,Ø	12
6	6	ACK	Channels 6,5,,Ø	14
7	7	BEL	Channels 7,6,,Ø	16
8	8	BS	Channels 8,7,,Ø	18
9	9	HT	Channels 9,8,,Ø	2Ø
1Ø	Α	LF	Channels 1Ø,9,,Ø	22

NOTE: There are three test channels that can be read: Ref+, Ref-, and Ref+/2. Specify 13 (ØDh) to read Ref+, 12 (ØCh) to read Ref-, and 11 (ØBh) to read Ref+/2.

232SDA12-0308 Manual

14

Reading Digital I/O Command

The Read Digital I/O command returns a byte which represents the states of the 3 digital input and 3 digital output states. Bits 3-5 correspond to the states of digital inputs \emptyset -2. Bits \emptyset -2 correspond to the states of digital outputs \emptyset -2. If a bit is a \emptyset then the digital state of that digital I/O is LOW. If a bit is a 1 then the digital state of the I/O is HIGH. Refer to Table 3.4 and 3.5.

Command Syntax

!ØRD

Unit Response

{states}

Where **{states}** is a byte in which Bits \emptyset -2 corresponds to the current states of Digital Outputs \emptyset -2 and Bits 3-5 corresponds to the current states of Digital Inputs \emptyset -2.

Table 3.4 - Read Digital I/O Response for Outputs

Response Byte			Digital Outputs		
Bit 2	Bit 1	Bit Ø	#2 #1 #9		#Ø
Ø	Ø	Ø	LOW	LOW	LOW
Ø	Ø	1	LOW	LOW	HIGH
Ø	1	Ø	LOW	HIGH	LOW
Ø	1	1	LOW	HIGH	HIGH
1	Ø	Ø	HIGH	LOW	LOW
1	Ø	1	HIGH	LOW	HIGH
1	1	Ø	HIGH	HIGH	LOW
1	1	1	HIGH	HIGH	HIGH

Table 3.5 - Read Digital I/O Response for Inputs

- and one included a signal of the period for impare									
R	esponse By	rte	Digital Inputs						
Bit 5	Bit 4	Bit 3	#2	#1	#Ø				
Ø	Ø	Ø	LOW	LOW	LOW				
Ø	Ø	1	LOW	LOW	HIGH				
Ø	1	Ø	LOW	HIGH	LOW				
Ø	1	1	LOW	HIGH	HIGH				
1	Ø	Ø	HIGH	LOW	LOW				
1	Ø	1	HIGH	LOW	HIGH				
1	1	Ø	HIGH	HIGH	LOW				
1	1	1	HIGH	HIGH	HIGH				

Set Digital Output Command

The Set Digital Output command is used to set the states of the 3 digital output lines. This command requires a data byte. The data byte is used to specify the output states. Bits \emptyset -2 correspond to the states of digital outputs \emptyset -2. If a bit is a \emptyset then the output will be set LOW. If a bit is a 1 then the output will be set HIGH. Refer to Table 3.6. NOTE: This command ignores Bits 3-7 of the data byte.

Command Syntax

!ØSO{states}

Where **{states}** is a byte in which Bits Ø-2 correspond to the outputs states of Digital Outputs Ø-2 Unit Response no response

Table 3.6 - Set Digital Output Data Byte Values

	Data Byte		Digital Outputs			
Bit 2	Bit 2 Bit 1 Bit Ø		#2	#1	#Ø	
Ø	Ø	Ø	LOW	LOW	LOW	
Ø	Ø	1	LOW	LOW	HIGH	
Ø	1	Ø	LOW	HIGH	LOW	
Ø	1	1	LOW	HIGH	HIGH	
1	Ø	Ø	HIGH	LOW	LOW	
1	Ø	1	HIGH	LOW	HIGH	
1	1	Ø	HIGH	HIGH	LOW	
1	1	1	HIGH	HIGH	HIGH	

232SDA12-0308 Manual

16

Chapter 4 - A/D

This chapter will deal with manipulating an A/D reading and cover some of the aspects that were not explained in the A/D Connections chapter.

Sampling Rate

The A/D converter has a conversion time of around 1Ø microseconds, however the sampling rate is limited by the serial communications. The sampling rate for a single channel is around 12Ø samples per second (96ØØ baud). This rate drops to 25 samples per second when sampling all of the channels. When reading an A/D input, the 232SDA12 takes four readings and returns the average (Ø.5 and greater are rounded up) of these readings. This averaging filters out noise.

A/D Input Range

The A/D input range on the 232SDA12 is from \emptyset to +5V DC. If it is possible for your device to output a voltage that doesn't fall in this range, steps must be taken to ensure that the voltage remains between \emptyset and +5V DC.

Reference Inputs

The A/D reference inputs set the top and bottom of the data range. A/D Ref Input- sets the bottom of the data range. A/D Ref Input+ sets the top of the data range. Since these inputs are directly related to the data range, it is important that a precision reference is used. The 232SDA12 has a 5V DC +/- Ø.5% reference available. The voltage on A/D Ref Input+ must be at least 2.5V DC greater than A/D Ref Input-. The voltage difference between A/D Ref Input+ and A/D Ref Input- is referred to as the Reference Range.

Reference Range = (A/D Ref Input+) - (A/D Ref Input-) Typically A/D Ref Input- is connected to Analog ground and A/D Ref Input+ is connected to +5V DC. Figure 2.1 in Chapter 2 shows the typical connections for a reference range of Ø to 5V DC.

Data Range

The data range of the A/D converter is determined by A/D Ref Input+ and A/D Ref Input-. A/D Ref Input- sets the bottom of the data range. Any input voltage that is less than or equal to the A/D Ref Input- will be read as a zero. A/D Ref Input+ sets the top of the data range. Any input voltage that is greater than or equal to the A/D Ref Input+ will be read as a 4Ø95 (ØFFFh). The data range is as follows:

Data Range = (A/D Ref Input-) to (A/D Ref Input+)

Data Range = Ø to 4Ø95

Data Range = Ø to ØFFFh

Figure 4.1 shows the Data Range and A/D Ref Inputs relationship.




Figure 4.1 - A/D Converter Data Range

Converting Data

The data read from the 232SDA12 A/D converter is directly related to the A/D input channel and the reference range (discussed in previous sections). The 232SDA12 has a 12-bit A/D converter. A 12-bit A/D has 1Ø24 possible output values, Ø to 4Ø95 (Ø to ØFFFh). These 4Ø96 output values are divided into equal steps over the reference range. The size of each step can be computed as follows:

Step size = (Reference Range) / 4Ø95

232SDA12-0308 Manual

18

The step size is also referred to as the resolution. Once the step size is known, all that is needed to determine the voltage of an A/D input is the number of steps. The data returned from the 232SDA12 is the number of steps. The voltage at the A/D inputs can be calculated as follows:

Voltage = (# of steps) * (Step size)

Example 4.1 - Assume: A/D Ref. Input + = 5.ØV DC and A/D

Ref.Input - = \emptyset V DC.

Therefore:

Reference Range = (A/D Ref. Input +) - (A/D Ref. Input -)

Reference Range = (5.ØV DC) - (ØV DC)

Reference Range = 5.ØV DC

Step size = (Reference Range) / 4Ø95

Step size = (5.ØV DC) / 4Ø95 Step size = 1.221 millivolts

Example #1: A/D reading = 4Ø95 (ØFFFH)

A/D voltage = reading * step size

A/D voltage = 4Ø95 * 1.221 millivolts

A/D voltage = 5.Ø Volts

Example #2: A/D reading = Ø

A/D voltage = \emptyset * 1.221 millivolts

A/D voltage = Ø Volts

Example #3: A/D reading = 675 (2A3H)

A/D voltage = 675 * 1.221 millivolts

A/D voltage = Ø.8242 Volts

Chapter 5 - Software

This chapter covers programming techniques such as constructing a command string, receiving data and manipulating data. The various steps and examples are shown in QuickBasic. If you are programming in another language, these sections can be used as a guideline for programming the 232SDA12.

Read A/D Command

The Read A/D channels command returns two bytes for each channel read. The two bytes represent the most significant byte (MSB) and least significant byte (LSB) of the reading. The MSB is received first, followed by the LSB. This command requires a data byte. The data byte is used to specify the number of the highest channel to be read. All channels less than this channel will be read as well.

The steps to reading an A/D command are given below:

1. Constructing the command string:

Command\$ = "!ØRA" + CHR\$(channel)

The value of **channel** is equal to the highest channel to be read.

2. Transmitting the command string:

Print #1, Command\$;

3. Receiving the data:

MSB\$ = INPUT\$(1, #1) LSB\$ = INPUT\$(1, #1)

4. Manipulating the data:

reading = (ASC(MSB\$) * 256) + ASC(LSB\$)

The value of **reading** is the result of the A/D conversion.

5. Repeat Steps 3 & 4 until each channel has been completed.

```
Example 5.1 - Read A/D channels 1 and Ø
```

channel = 1

Command\$ = "!ØRA" + CHR\$(channel)

Print #1, Command\$;

'Get the value of channel 1

MSB = INPUT\$ (1, #1)

LSB\$ = INPUT\$ (1, #1)

reading1 = (ASC(MSB\$) * 256) + ASC(LSB\$)

'Get the value of channel Ø

MSB = INPUT\$ (1, #1)

LSB\$ = INPUT\$ (1, #1)

readingØ = (ASC(MSB\$) * 256) + ASC(LSB\$)

The value of **reading1** is the result of the A/D conversion on channel 1. The value of **readingØ** is the result of the A/D conversion on channel Ø.

Read Digital I/O Command

The Read Digital I/O command returns a byte which represents the states of the 3 digital input and 3 digital output states. Bits 3-5 correspond to the states of digital inputs \varnothing -2, and bits \varnothing -2 correspond to the states of digital outputs \varnothing -2. If a bit is a \varnothing then the digital state of that digital I/O is LOW. If a bit is a 1 then the digital state of the I/O is HIGH.

The steps to reading a digital I/O command are given below:

1. Constructing the command string:

Command\$ = "!ØRD"

2. Transmitting the command string:

Print #1, Command\$;

3. Receiving the data:

Reply\$ = INPUT\$ (1, #1)

4. Manipulating the data:

states = ASC(Reply\$)

5. Determining an I/O's status

status = states AND mask

Repeat Step 5 until the status of each I/O has been determined.

By "ANDing" the value of **states** with the appropriate **mask** of an I/O line, the **status** of can be determined. If **status** is equal to zero

then the I/O line is LOW. If **status** is not equal to zero then the I/O line is HIGH. Table 5.1 shows the **mask** values for each I/O.

Table 5.1 - Digital I/O Mask Values

	Mask Values					
I/O Line	Hexadecimal	Decimal				
Digital Output #Ø	1H	1				
Digital Output #1	2H	2				
Digital Output #2	4H	4				
Digital Input #Ø	8H	8				
Digital Input #1	1ØH	16				
Digital Input #2	2ØH	32				

Example 5.2 - Determining the status of Digital Input #1

mask = &H1Ø Command\$ = "!ØRD" Print #1, Command\$; Reply\$ = INPUT\$ (1, #1) states = ASC (Reply\$) status = states AND mask

If **status** is equal to zero then Digital Input #1 is LOW. If **status** is not equal to zero then Digital Input #1 is HIGH.

Set Digital Output States

The Set Digital Output command is used to set the states of the 3 digital output lines. This command requires a data byte. The data byte is used to specify the output states. Bits \emptyset -2 correspond to the states of digital outputs \emptyset -2. If a bit is a \emptyset then the output will be set LOW. If a bit is a 1 then the output will be set HIGH. NOTE: This command ignores Bits 3-7 of the data byte.

- 1) Constructing the command string:
 - a) Set Appropriate Outputs HIGH

states = states OR mask

By "ORing" the current **states** with the appropriate **mask** of a digital output (given in Table 5.1), the output's data bit will be set to a "1" (which will be set HIGH).

232SDA12-0308 Manual

22

b) Set Appropriate Outputs LOW

states = states AND (NOT(mask))

By "ANDing" the current **states** with the complement of the appropriate **mask** of a digital output (given in Table 5.1), the output's data bit will be set to a "Ø" (which will be set LOW).

c) Construct the string

Command\$ = "!ØSO" + CHR\$(states)

2) Transmitting the command string:

Print #1, Command\$;

Example 5.3 - Set Digital Output #Ø HIGH and Digital Output #2 LOW.

'Set bit Ø of states to make Digital Output #Ø HIGH

states = states OR 1

'Clear bit 2 of states to make Digital Output #2 LOW

states = states AND (NOT(4))
Command\$ = "!ØSO" + CHR\$(states)
Print #1, Command\$;

Digital Output #Ø will be set HIGH. Digital Output #2 will be set LOW. Digital Output #1 will not change. Note that the variable **states** is assumed to be value from Example 5.2.

Appendix A: Adding Data Field Confirmation

With serial communications in a laboratory environment, the possibility of a communication error occurring is minimal. However, in a harsh or an industrial environment the possibility increases. A communication error occurs when a bit transmitted as a "1" is received as a "Ø" or vice versa. If the 232SDA12 receives an error in one or more of the first four command characters ("!Øxx"), the unit will not execute the command. However, if the 232SDA12 receives a communication error on a data byte (channel byte for Read Analog command or state byte for Set Output State command), the command will be executed since the unit has no way of knowing that there was an error.

To provide the 232SDA12 with a way of detecting errors in the data fields, an additional set of commands can be used. This set of commands begins with the "#" (23h) character, instead of the "!" (21h) character. Refer to Table A-1. With these commands every data byte that is transmitted or received is followed by its complement.

Example A.1 - To read A/D channel zero:

Command syntax:

#ØRA{ØØ}{FF}

Response syntax:

{chØ msb}{~ chØ msb}{chØ lsb} {~ chØ lsb}

Where "~" is used to indicate the "complement of."

If A/D channel \varnothing has a reading of 1, the following would be received:

{ØØ}{FF}{Ø1}{FE}

Where FFh is the complement of \emptyset and FEh is the complement of 1. The complement of number "x" can be calculated in QuickBasic as follows:

comp = (NOT x) AND &HFF

Table A-1 - Extended Commands

Function	Command	Response			
Read A/D Channels	#ØRA{x}{~x}	{chxmsb}{~chxmsb}{chxlsb}{~ch xlsb}{ch(x-1)msb}{chØmsb} {~chØmsb}{chØlsb}{~chØlsb}			
Read Digital I/O	#ØRD	{I/O states}{~I/O states}			
Set Output States	#ØSO{x}{~x }	no response			

Where "x" is the required data byte and "~" signifies the complement of the specified byte.

A-2 Appendix A 232SDA12-0308 Manual

Appendix B: Analog Input Impedance

When interfacing with an A/D converter, it is important that the device you are connecting can drive the A/D input. To determine if your device can drive an A/D input, there are three factors you must consider:

- Output impedance of the device
- Input impedance of A/D
- A/D sampling time

The goal is to have the voltage at the A/D input settle to a voltage close to the output voltage of the device in a time frame that is less than the A/D sampling time. (close to means a value significantly less than the resolution of the A/D). If the voltage does not settle fast enough, errors will occur in the reading, resulting in a loss of resolution.

The next section, titled "Simplified Analog Input Analysis," contains information from Texas Instruments datasheet on the TLC1543. The TLC1543 is the A/D converter that is used on the 232SDA12. This section provides a simplified calculation which can be used to determine the maximum output impedance the device can have to settle the A/D input to a voltage within one half LSB.

For the 232SDA12:

 $t_{c} = 100us$

Using this information:

 $R_{\rm s} \leq 170 k\Omega$

If the output impedance of your device is $17\emptyset k\Omega$, you should figure an additional error of ½ LSB.

It should be pointed out that **this is a simplified analysis** and there other several other factors that must be considered (pin capacitance, noise immunity, etc.). The datasheet for the TLC2543 states that "The driving source impedance should be less than or equal to $1k\Omega$." B&B Electronics recommends placing a voltage follower between the 232SDA12 and any device with output source impedance greater than $1k\Omega$.

Simplified Analog Input Analysis

Using the equivalent circuit in Figure B-1, the time required to charge the analog input capacitance from \varnothing to Vs within ½ LSB can be derived as follows:

The capacitance charging voltage is given by

$$V_{c} = V_{s}(1 - e^{-t_{c}/R_{t}C_{i}})$$
 (1)

where

$$R_t = R_s + r_i$$

The final voltage to ½ LSB is given by

$$V_c(1/2 LSB) = V_s - (V / 8192)$$
 (2)

Equating equation 1 to equation 2 and solving for time t_c gives

$$V_s - (V / 8192) = V_s (1 - e^{-t_c/R_t C_i})$$
(3)

and

$$t_c(1/2 LSB) = R_t \times C_i \times \ln(8192)$$
 (4)

Therefore, with the values given the time for the analog input signal to settle is

$$t_c(1/2 LSB) = (R_s + 1k\Omega) \times 60pF \times ln(8192)$$
 (5)

This time must be less than the converter sample time shown in the timing diagrams.

V_I = Input Voltage at AØ - A1Ø

V_S = External Driving Source Voltage

R_s = Source Resistance

r_i = Input Resistance

C_i = Equivalent Input Capacitance

*Driving source requirements:

- Noise and distortion for the source must be equivalent to the resolution of the converter.
- R_s must be real at the input frequency.




Figure B-1. Equivalent Input Circuit Including the Driving Source

Appendix C: Decimal to HEX to ASCII Table

Table C-1: Decimal to HEX to ASCII Table

DECIMAL to HEX to ASCII CONVERSION TABLE												
DEC HEX ASCII KEY DEC HEX ASCII DEC HEX ASCII DEC HEX ASC								ASCII				
0	0	NUL	ctrl @	32	20	SP	64	40	@	96	60	`
1	1	SOH	ctrl A	33	21	!	65	41	Α	97	61	а
2	2	STX	ctrl B	34	22	"	66	42	В	98	62	b
3	3	ETX	ctrl C	35	23	#	67	43	С	99	63	С
4	4	EOT	ctrl D	36	24	\$	68	44	D	100	64	d
5	5	ENQ	ctrl E	37	25	%	69	45	Е	101	65	е
6	6	ACK	ctrl F	38	26	&	70	46	F	102	66	f
7	7	BEL	ctrl G	39	27		71	47	G	103	67	g
8	8	BS	ctrl H	40	28	(72	48	Н	104	68	h
9	9	HT	ctrl I	41	29)	73	49	- 1	105	69	i
10	Α	LF	ctrl J	42	2A	*	74	4A	J	106	6A	j
11	В	VT	ctrl K	43	2B	+	75	4B	K	107	6B	k
12	С	FF	ctrl L	44	2C	,	76	4C	L	108	6C	- 1
13	D	CR	ctrl M	45	2D	-	77	4D	М	109	6D	m
14	Е	so	ctrl N	46	2E		78	4E	N	110	6E	n
15	F	SI	ctrl O	47	2F	/	79	4F	0	111	6F	0
16	10	DLE	ctrl P	48	30	0	80	50	Р	112	70	р
17	11	DC1	ctrl Q	49	31	1	81	51	Q	113	71	q
18	12	DC2	ctrl R	50	32	2	82	52	R	114	72	r
19	13	DC3	ctrl S	51	33	3	83	53	S	115	73	s
20	14	DC4	ctrl T	52	34	4	84	54	Т	116	74	t
21	15	NAK	ctrl U	53	35	5	85	55	U	117	75	u
22	16	SYN	ctrl V	54	36	6	86	56	V	118	76	٧
23	17	ETB	ctrl W	55	37	7	87	57	W	119	77	w
24	18	CAN	ctrl X	56	38	8	88	58	Х	120	78	х
25	19	EM	ctrl Y	57	39	9	89	59	Υ	121	79	у
26	1A	SUB	ctrl Z	58	ЗА	:	90	5A	Z	122	7A	z
27	1B	ESC	ctrl [59	3B	;	91	5B]	123	7B	{
28	1C	FS	ctrl \	60	3C	<	92	5C	\	124	7C	1
29	1D	GS	ctrl]	61	3D	=	93	5D]	125	7D	}
30	1E	RS	ctrl ^	62	3E	>	94	5E	٨	126	7E	~
31	1F	US	ctrl _	63	3F	?	95	5F	-	127	7F	DEL

232SDA12-0308 Manual

Appendix C

C-1